

Keep the following points in mind while doing the work of concrete finishing.

01



Firstly, get the screeding done. In screeding, the upper layer of the excess concrete is removed. This gives us levelled surface.

02

The next step is floating. In this, the big aggregates are neatly set with the help of a wooden float.



03



The last step is trowelling, in which the steel trowel is used. This helps you in giving very smooth, uniform surface.



For more information on home-builing, [click here](#).