

The logo for UltraTech, featuring the brand name in a bold, italicized, black sans-serif font on a bright yellow rectangular background.The text 'FREEFLOW +' in a bold, white, sans-serif font, centered on a black rectangular background.

Checklist for FreeFlow Plus

1. Formwork should be strong enough
 - a. to hold the weight and flow of concrete
 - b. to prevent leakage of concrete
2. Tests for filling ability, passing ability & segregation resistance should be conducted at the design stage.
3. Curing should start as soon as initial setting of concrete is achieved
4. Curing should be done by water sprinkling/ curing compound/ curing blanket (no jute bag curing allowed)